


# **EQUINOX**

## **SLENDER BEAM QUAD**



**User Manual**

**EQLED012**

## **Contents**

1. Safety Instructions
2. Features & Specifications
3. How To Set The Unit
4. Troubleshooting
5. Fixture Cleaning

## 1. Safety Instruction



### WARNING

Please read the instructions carefully as they include important information about installation, usage and maintenance.

Please keep this User Guide for future consultation. If you sell the unit to another user be sure that they also receive this.

Unpack and check carefully that there is no transportation damage before using the unit.

- Before operating, ensure that the voltage and frequency of the power supply match the power requirements of the unit.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- The unit is for indoor use only. Use only in a dry location.
- The unit must be installed in a location with adequate ventilation, at least 50cm from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Disconnect the mains power before replacement or servicing.
- Make sure there are no flammable materials close to the unit while operating as they may cause a fire hazard.
- Always use a safety cable when installing this unit. Do not carry the unit by its head; always carry it using the base.
- The maximum ambient temperature is: 40°. Don't operate it where the temperature is higher than this.
- In the event of a serious operating problem stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Do not touch any power cables during operation as the high voltage may cause an electric shock.

## Warning

- To prevent or reduce the risk of electrical shock or fire, do not expose the unit to rain or moisture.  
Do not open the unit within five minutes after switching off.
- The housing and lenses must be replaced if they are visibly damaged.

## Installation

The unit should be mounted via its screw holes onto the bracket. Always ensure that the unit is firmly fixed to avoid vibration and slipping while operating. Make sure that the structure to which you are attaching the unit to is secure and is able to support a weight of 10 times of the unit's weight. Always use a safety cable that can hold 12 times of the weight of the unit when installing the fixture.

The equipment must be installed by professionals and it must be installed in a place where is out of the reach of people and no one can pass by or under it.


## 2. Features & Technical Specifications

- Control: Sound active, auto, Master/slave and DMX-512 modes
- DMX Channels: 1CH/7CH
- Electronic dimming: 0-100%
- Compact size and light-weight

<b>Voltage:</b>	100V~240V, 50/60Hz
<b>Fuse:</b>	T 2.5A
<b>Power consumption:</b>	26W
<b>Light source:</b>	1 x 10W quad-colour LED
<b>Dimension:</b>	270 x 160 x 110mm
<b>Weight:</b>	2.5 kg
<b>Pan/Tilt:</b>	540°/180°
<b>Power sockets:</b>	IEC
<b>XLR sockets:</b>	3-pin XLR IN/OUT

### 3. How To Set The Unit

#### 3.1 Control panel



#### Display

Shows the various menus and selected functions

#### Button

MENU	Selects the programming functions
UP	To go forward in the selected functions
DOWN	To go backward in the selected functions
ENTER	Confirms the selected functions

#### Mains input

Connection to the power supply.

#### DMX input/output

For DMX-512 linking. Use a 3-pin XLR cables to link to the controller or to other units.

#### 3.2 Main Functions

To select any of the given functions, press the **MENU** button up to where the required function is showing on the display. Select the function by pressing the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to change the mode. Once the required mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes, press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

### The main functions are as below:

Menu	ADDR	001-512
	CHND	1CH/7CH
	SLND	MAST
		SL1
		SL2
	SHND	SH1
		SH2
		SH3
		SH4
	SOUN	ON
		OFF
	SENS	000-100
	LED	ON
		OFF
	DISP □ INVERT	
	PAN INVERT	YES
		NO
	TILT INVERT	YES
		NO
	TEST	
VER		
RSET		

## Addr DMX Address Setting

Press the **MENU** button until **Addr** is showing on the display. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to change the DMX-512 address. Once the address has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button one second or wait for one minute to go back to the main menu.

## Chnd Channel Mode

Press the **MENU** button to select **Chnd**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **1Ch** (1 Channel) or **7Ch** (7 Channel) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## MaSt Master Mode or SLNd Slave Mode

Press the **MENU** button to select **SLNd**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **SL1** (Slave 1), **SL2** (Slave 2) or **MaSt** (Master) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## Shnd Show Mode

Press the **MENU** button to select **Shnd**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **Sh1** (show 1) or **Sh2** (show 2) or **Sh3** (show 3) or **Sh4** (show 4) mode.

NOTE: For the fixture to function in show mode, you will first need to select "MASTER" mode and not "SLAVE 1" or "SLAVE 2".

## SOuN Sound Mode

Press the **MENU** button to select **SOuN**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **on** (sound on) or **oFF** (sound off) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## SEnS Sound Sensitivity

Press the **MENU** and use the **UP** and **DOWN** buttons to select **SEnS** and select the sound sensitivity between value 0 and 255. Press the **ENTER** button for confirmation after value selection. To go back to the functions without any changes press the **MENU** button again.

## LEd Led Display

Press the **MENU** button to select **LEd**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **on** (Led display on) or **oFF** (Led display off) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

NOTE: If "OFF" is selected the LED display will go off after 5 seconds and will come back on when any button is pressed.

## **DISP** Display Inversion

Press the **MENU** button to select **DISP**. Press the **ENTER** button to change the mode **DISP** (display normal), It will be automatically saved after 8 seconds. Press the **ENTER** button again to select the mode **DISP** (display inversion). To go back to the functions press the **MENU** button. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

**DISP** Display normal mode is for floor standing the unit.

**DISP** Display inversion mode is for hanging the unit upside down.

## **PAN** Pan Inversion

Press the **MENU** button to select **PAN**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **no** (normal) or **YES** (pan inversion) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## **TILT** Tilt Inversion

Press the **MENU** button to select **TILT**. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to select the **no** (normal) or **YES** (tilt inversion) mode. Once the mode has been selected, press the **ENTER** button to confirm. To go back to the functions without any change press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## **TEST** Auto-Test

Press the **MENU** button to select **TEST**. Press the **ENTER** button and the unit will run a self-test with its built-in programs. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button for one second or wait for one minute to go back to the main menu.

## **RESET** Reset

Press the **MENU** button to select **RESET**. Press the **ENTER** button and all channels of the unit will return to their standard position.

## **4. How To Control The Unit**

1. Master/slave built-in preprogram function
2. Universal DMX controller

There is no need to turn the unit off when you change the DMX address as new DMX address setting will be effected at once. Every time you turn the unit on, it will show "DPFC" on the display and move all the motors to their 'home' position and you may hear some noises for about 20 seconds. After that the unit will be ready to receive a DMX signal or run the built in programs.

### **4.1 Master/Slave Built In Preprogrammed Function**

By linking the units in master/slave connection, the first unit will control the other units to give an automatic, sound activated, synchronized light show. This function is good when you want an instant show. You have to set the first unit as master and select **show 1**, **show 2**, **show 3** or **show 4** from the **Show Mode**. The other units must be set to either **Slave 1** (normal) or **Slave 2** (2 light show) mode. A DMX cable between the units for daisy chaining is needed.

## 2-light show

In **slave mode**, **Slave 1** means the unit works normally and **Slave 2** means 2-light show. In order to create a great light show, you can set **Slave 2** on the second unit to get contrast movement to each other, even if you have two units only.

## 4.2 DMX Controller

By using a universal DMX controller to control the units, you will need to set a DMX address from 1 to 512 so that the units can receive a DMX signal. Press the **MENU** button until **Addr** is showing on the display. Press the **ENTER** button and the display will blink. Use the **DOWN** and **UP** buttons to change the DMX-512 address. Once the address has been selected, press the **ENTER** button to confirm. To go back to the functions without any changes press the **MENU** button again. Press and hold the **MENU** button one second or wait for one minute to go back to the main menu.

Please refer to the below diagram to address your first 4 units :

Channel mode	Unit 1 Address	Unit 2 Address	Unit 3 Address	Unit 4 Address
1 channel	1	2	3	4
7 channel	1	8	15	22

## 4.3 DMX 512 Configuration

### 1 CHANNEL MODE:

Channel	Value	Function
1	000-007	Blackout
	008-067	Show 1
	068-127	Show 2
	128-187	Show 3
	188-255	Random shows

### 7 CHANNEL MODE:

Channel	Value	Function
1	0-255	Pan
2	0-255	Tilt
3	0-255	PAN/TILT Speed (slow-fast)
4	0-255	Dimmer
5	0-255	Strobe(slow-fast)
6	0-017	Red.
	018-034	Green.
	035-051	Blue.
	052-068	White.
	069-085	Red + Green
	086-102	Red + Blue
	103-119	Red + white
	120-136	Green + Blue
	137-153	Green + White
	154-170	Blue + White
	171-187	Red +Green + Blue
	188-204	Red +Green +White
	205-221	Red + blue + White
222-238	Green + blue + White	
239-255	Red +Green + Blue + White	
7	000-010	NO FUNCTION
	011-255	Sound

## **4. Troubleshooting**

**Following are a few common problems that may occur during operation and some suggestions for easy troubleshooting:**

### **A. The unit does not work, no light and the fan does not work**

1. Check the connection of the power and the main fuse.

### **B. Not responding to DMX controller**

1. DMX LED should be on. If not, check DMX cables to see if linked correctly.
2. If the DMX address is showing but no response to the controller, check the address settings and DMX polarity.
3. Try another DMX controller.

### **C. No response to the sound**

1. Make sure the unit is not receiving a DMX signal.
2. Check the microphone to see if it is good by tapping it. The microphone is located on the bottom plate of the unit.

## **5. Fixture Cleaning**

The cleaning of external optical lenses must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the fixture operates: damp, smoky or particularly dirty surrounding can cause a greater accumulation of dirt on the unit's optics.

Clean with a soft cloth using normal glass cleaning fluid or mild soapy water.

- Always dry the parts carefully.
- Clean the external optics at least every 20 days.