
ASSEMBLY GUIDE


Easy Assembly Guide

<u>Unboxing your new piano</u>

Remove the Piano Stand and the piano from its packaging.

Also Included in the box:






Be sure to unpack the enclosed hardware from the box and check it with the list above.

Piano Assembly

Attaching the brackets:

Begin assembly by attaching the brackets to the legs as shown here.

- A. Attach each bracket using three (A) screws .
- B. Make sure that the (C) Brackets are facing the top of the leg.
- C. Make sure the (B) brackets are facing the front of the leg.




Assembling the stand:

Begin assembling the piano by attaching the legs of the stand with the back panel:

A. Insert 2 (D) bolts into the each side of the crosspiece.

B. Screw bolts into the brackets on each leg, make sure that the crosspiece and the feet are all facing toward you.

C. Tighten until the crosspiece is flush with the leg brackets, and the legs are firmly attached.



Attaching the piano:

Attach the piano body to the stand using four (E) bolts

A. Rest the piano on the stand and line up the hole s in the bottom of the piano with the holes in the brackets on the leg.

B. Make sure that the piano and legs are facing the same way.


C. Tighten (E) bolts into each hole until the piano sits flush on the legs and is firmly attached.



Assembling the bench:

The bench is assembled using kernel locking joiners.

A. Insert a kernel screw into the four holes in the bottom of the seat, and two center holes in each leg. Circled here in red. Tighten with a screwdriver.



C. Repeat step B to attach seat.

D. Finish assembly by covering the locking nuts with plastic covers (C)





