










PORTABLE STAGE


EXAMPLE SETUP GUIDE

COMPONENTS


Here is an example contents list, including component parts of the Gear4music Portable Stage range.

<p>①</p>  <p>STAGE RISER</p>	<p>②</p>  <p>STAGE PLATFORM</p>	<p>③</p>  <p>STAGE HANDRAIL</p>
<p>④</p>  <p>STEP RISER</p>	<p>⑤</p>  <p>STEP PLATFORM</p>	<p>⑥</p>  <p>STEP HANDRAIL</p>
<p>Ⓐ</p>  <p>STAGE CLAMP</p>		


TOOLS REQUIRED




1




2




3





4




5




6




7




8




9




10




11




12




13




14




15



16





WWW.GEAR4MUSIC.COM

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**