



Junior 3 Piece Drum Kit by Gear4music Contents
and Assembly Instructions





Your Drum Kit





Contents Checklist

Your junior 3 piece drum kit will arrive in one box and will only take around 20 minutes to fully assemble. Simply follow the instructions below and your new drum kit will be ready to play in no time at all!

When you open the box, you'll find the drum kit packaged in two layers separated by protective packaging. The layers contain the following components, please check that you have them all:

Layer one contains:

2 x Bass Drum Heads 16"

Layer two contains:

Packaged inside the 16" x 12" Bass Drum (which has the 16" Bass Drum Hoops attached, but not secured) are: 1 x 10" x 5" Snare Drum with drum heads and drum hoops attached / 1 x 8" x 7" Tom Tom Drum with drum heads and drum hoops attached / 1 x Drum Throne Padded Seat / 1 x Crash Cymbal.

Around the edge of the box are: 1 x Bass Drum Pedal and Beater (packaged together) / 1 x Cymbal Arm / 1 x Tom Tom Arm / 12 x Bass Drum Claws, Tension Rods and Washers (packaged together) / 2 x Bass Drum Legs and 1 x Pair of Drum Sticks (packaged together).



Assembly Instructions

Page 1

Bass Drum

What you will need: Bass Drum / Both Bass Drum Heads / All Bass Drum Tension Rods, Claws & Washers / Bass Drum Pedal / Bass Drum Hoops / Bass Drum Legs / Drum Key.

1. Lay the bass drum on its side so the tom tom mount and bass drum leg mounts are closer to the floor. Take the bass drum head, without the Gear4music logo on it, and place it over the drum. Place one of the bass drum hoops over the top of the skin and attach by screwing 6 x tension rods, claws and washers into the 6 lugs (which are attached to the bass drum) with the drum key. Continue until the drum head is tight and firmly in place.
2. Repeat the process on the other side of the drum using the bass drum head with the Gear4music logo on, making sure the logo is in line with the tom mounts.
3. Take the 2 x bass drum legs and insert them into the holes on each side of the bass drum. Tighten to secure them. Stand the bass drum up and clamp the bass drum pedal, with beater inserted, to the hoop on the opposite side to the bass drum legs.

Tom Drum

What you will need: 1 x Tom Tom Drum / 1 x Tom Tom Arm.

1. Your tom tom drum will arrive set-up and will just need mounting to the drum kit. Take the tom tom arm and insert the longest tube into the tom mount hole on the bass drum, if you are right handed insert into the left mount, if you are left handed place insert into the right mount. Tighten the screw to secure it at a suitable height.
2. Unscrew the arm joint, and adjust the angle of the tom arm, so the arm is pointing outwards.
3. Take the tom drum and insert it over the tom arm.



Snare Drum

What you will need: Snare Drum / Snare Drum Stand.

1. The snare drum arrives set-up. Therefore, all you need to do is spread the snare drum stand legs out and tighten the screws so the stand is sturdy. Sit the snare in the cradle and tighten the wing nuts so the stand holds the drum in place. The height and angle of the snare drum can be altered by adjusting different parts of the stand.

Cymbal

What you will need: Crash Cymbal / Cymbal Arm

1. Insert the cymbal arm into the remaining mounting hole on the bass drum. Unscrew the wing nut at the top of the cymbal stand, removing one, of two, felts at the same time.
2. Place the crash cymbal onto the top of the stand, resting it on the second felt, and retighten the wing nut and removed felt. Do not over tighten the cymbal, it requires space to move freely when hit. Over tightening can cause a cymbal to split. The angle of the cymbal can be adjusted by altering of the cymbal joint on the stand.

The drum stool is assembled by opening the legs as far as they will go and screwing the padded seat into position. Adjust the height to suit you.

Your drum kit is now set up and will simply need tuning before playing.

Drum and cymbal positioning is personal preference and the layout of a drum kit can vary, however please feel free to refer to the images on our website.

If you require any further assistance, please feel free to contact us:

info@gear4music.com / 0330 365 4444