












**SAMSUNG**




Unpacking and Installation Guide  
 Guide de déballage et d'installation  
 Guía de desembalaje e instalación  
 Manual de desempacotamento e instalação  
 Auspacken und Installationsanleitung  
 Guida al disimballaggio e all'installazione  
 Руководство по распаковке и установке  
 Қаптамадан шығару және орнату нұсқаулығы  
 Посібник з розпаковки та встановлення  
 Qadoqdan chiqarish va o'rnatish qo'llanmasi





7



8




9



	A	B	C	D	E	F	G	H
77S9*D 77SD9*	67.7 inches (1718.5 mm) (171.85 cm)	38.9 inches (987.6 mm) (98.76 cm)	1.8 inches (44.9 mm) (4.49 cm)	41.7 inches (1058.6 mm) (105.86 cm)	14.1 inches (359.0 mm) (35.90 cm)	76.6 inches (194 cm)	71.4 lbs (32.4 kg) (32,4 kr)	75.4 lbs (34.2 kg) (34,2 kr)
83S9*D 83SD9*	72.9 inches (1851.0 mm) (185.10 cm)	41.8 inches (1062.8 mm) (106.28 cm)	1.8 inches (44.9 mm) (4.49 cm)	44.6 inches (1133.7 mm) (113.37 cm)	14.1 inches (359.0 mm) (35.90 cm)	82.5 inches (209 cm)	82.9 lbs (37.6 kg) (37,6 kr)	86.9 lbs (39.4 kg) (39,4 kr)

\*: 0-9, A-Z



	VESA A x B (mm) VESA A x B (mm)	C (mm) C (mm)	D x 4
77S9*D 77SD9*	400 x 300	28-30	M8
83S9*D 83SD9*			

\*: 0-9, A-Z