

Premier
NXT II GEN

**PEDAL GLOCKENSPIEL,
3.0 OCTAVE**

PNG-OG3.0


SETUP GUIDE

PARTS


A x1




B x1




C x1




D x1




E x1



F x1




G x1




H x4




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



STEP 7



STEP 8



Premier
NXT || GEN

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: +44 (0) 330 365 4444 or info@gear4music.com

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND
WWW.GEAR4MUSIC.COM