


Premier
NXT || GEN

**CONCERT BASS
DRUM & CRADLE**


PNG-OB3618CR

SETUP GUIDE

PARTS



A x2




B x1



C x1



D x2



E x2



F x2




G x12




H x1


STEP 1





STEP 2




STEP 3




STEP 4**STEP 5**

STEP 6



STEP 7



Premier
NXT || GEN

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: +44 (0) 330 365 4444 or info@gear4music.com

*KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND
WWW.GEAR4MUSIC.COM*