



ZEN Phono


Quick Start Guide



Set-Up video




1 Power




Press POWER button



2 Input




3 Output



4 Gain





MM	36dB
MC HIGH	48dB
MC LOW	60dB
MC V-LOW	72dB



5 Load

Check the cartridge datasheet and select your closest load value



6 Subsonic filter

