




Thank you for purchasing the G4M Electric Violin, to get the most out of your product, please read this manual carefully.

BOX CONTENTS


- 1x G-EV-4 Electric Violin
- 1x Bridge
- 1x User Manual

FUNCTIONS



FRONT

- 1. TUNING PEGS**
Use these to tune the violin
- 2. FINGERBOARD**
- 3. BRIDGE**
When positioning the bridge, use the higher side of the bridge for the lower (thicker) strings
- 4. TAILPIECE**
Fine tuners can be used to micro adjust the pitch of the strings
- 5. CHINREST**



BACK

- 6. VOLUME**
This can be used to adjust the output volume of the violin
- 7. TONE**
This can be used to adjust the tone of the violin
- 8. OUTPUT JACK**
Used to connect the violin to an amplifier

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on:
+44 (0) 330 365 4444 or info@gear4music.com

WWW.GEAR4MUSIC.COM
KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

