


















Hartwood




**WOODEN
GUITAR RACK**



HW-WGR7
SET-UP GUIDE


<p>①</p>  <p>X1</p>	<p>②</p>  <p>X2</p>		
<p>③</p>  <p>X1</p>	<p>④</p>  <p>X1</p>		
<p>⑤</p>  <p>X1</p>	<p>⑥</p>  <p>X1</p>		
<p>⑦</p>  <p>X1</p>	<p>A</p>  <p>X12</p>		
<p>B</p>  <p>X4</p>	<p>C</p>  <p>X2</p>	<p>D</p>  <p>X4</p>	<p>F</p>  <p>X4</p>
<p>E</p>  <p>X1</p>			











NOTE: Please mind your fingers when folding down the rack.

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**