









Projector Tripod Stand

AC-PJSTD

Parts Checklist

AC-PJSTD



PART	DESCRIPTION	QTY
1		1
2		1
3		1
4		1
5		1

PART	DESCRIPTION	QTY
A		4
B		4
C		1
D		1
E		1


TOOL REQUIRED


Adjust the Tripod


AC-PJSTD




Step 1



Step 2



Step 3




Adjust the Pillar


AC-PJSTD



Step 4



Step 5




Connect the Tray


AC-PJSTD



Step 6



Step 7




Install Phone Holder


AC-PJSTD



Step 8



Step 9 - Adjust the Tray




Secure the Device to the Tray

AC-PJSTD



Step 10

PART	DESCRIPTION	QTY
D		1



AC-PJSTD



www.av.com

Unit 4 The Sidings | New Line Industrial Estate | Bacup | OL13 9RW
Kettlestring Lane | York | YO30 4XF | United Kingdom
Lahnstraße 27 | 45478 Mülheim An Der Ruhr | Deutschland

if you have any more questions about this product, please do not hesitate to contact the Gear4music customer service team on: +44 (0) 330 365 4444 or info@gear4music.com