


Premier
NXT II GEN

**CONCERT BASS
DRUM & CRADLE**


PNG-OB3618CR

SETUP GUIDE

PARTS




A x2



B x2



C x2



D x2



E x4




F x8




G x1


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5



STEP 6



STEP 7



Premier
NXT || GEN

*If you have any more questions about this product, please do not hesitate to contact the Gear4music
Customer Service Team on: +44 (0) 330 365 4444 or info@gear4music.com*

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND
WWW.GEAR4MUSIC.COM