SubZero

CONCERT EAR PLUGSSZ-CEP USER MANUAL

Thank you for purchasing the Subzero SZC -450. To get the most out of your product, please read this manual carefully.

BOX CONTENTS

- 1x SubZero Pro Concert Earplugs
- 1x Aluminium Capsule
- 3x Pairs of Different Sized Earplug Tips
- 1x Carry Case
- 1x Manual

FEATURES

- · Comfortable and Lightweight Material
- 3 Sizes of Earbud Tips for a Perfect fit
- Removeable Attenuation Disc for Variable Noise Protection
- Convenient Carry Case Included

SPECIFICATIONS

SZ-CEP-2

Weight (Earbuds Only)	. 3g
Weight (Earbuds and Capsule)	. 21g
Total Weight	. 76g
Noise Reduction	. 26 dB (Lo Freq. = 21dB, Mid
	Freq. = 22dB, Hi Freq. = 28dB)
Material	. Synthetic Rubber, ABS Plastic
Carry Case Size	100x100mm

SZ-CEP-1	
Weight (Earbuds Only)	2g
Weight (Earbuds and Capsule)	20g
Total Weight	75g
Noise Reduction	26 dB (Lo Freq. = 21dB, Mid
	Freq. = 22dB, Hi Freq. = 28dB)
Material	Synthetic Rubber
Carry Case Size	100x100mm

INSTRUCTIONS

How to Properly Insert your Earplugs

1. Gently insert the earplug into your ear



2. Twist the earplug into your ear to ensure a snug fit



3. Check that the external part of the earplug lies flat against your ear and is barely visible from the front



Cleaning and Maintenance

To clean the earbuds, soak a clean cloth in warm soapy water, wipe clean and pat dry with a clean dry cloth. Then leave to completely dry in a cool dry place. It is normal for the earbuds to have a synthetic rubber odour. To reduce this, follow the instructions above and leave to dry in the open air for 24 hours.

Note:


Do not wash with boiling water or leave to dry on a heated surface as this will damage the product.

Do not give to a child under the age of 3 as the product may pose as a choking hazard.

If you experience severe discomfort or an allergic reaction, please stop using the product immediately and consult a doctor.

Replacing your Earbud Tips

- 1. Gently twist the existing earbud tip off of the earplug
- 2. Invert the new earbud tips to properly align the plug to the tip
- 3. Gently push and twist the new earbud in place



WWW.GEAR4MUSIC.COM
KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRAßE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on:
+44 (0) 330 365 4444 or info@gear4music.com