



J. ROCKETT AUDIO DESIGNS



Controls

- **Volume:** When turned to the right the volume increases, when turned to the left the volume decreases.
- **Tone:** When turned to the right the higher frequencies are increased, when turned to the left the higher frequencies are reduced.
- **Gain:** When turned to the right the gain is increased, when turned to the left the gain is decreased.

Settings

The Chicken Soup OD is a pretty self-explanatory pedal with simple controls and a simple application. It has the standard volume, gain, and tone knobs. It is advised that you experiment with all the settings since they offer a variety of tones and feel.

We recommend that you start with all control knobs at 12:00 o'clock. It is very easy to find an abundance of great sounds out of this pedal. If you reduce the gain and increase the volume the pedal will churn out all those classic, country tones you hear from great players throughout Nashville! With the gain increased you can get those scorching and compressed lead tones. This pedal is great for Telecasters and Strats but it's equally compatible with Les Paul's and guitars equipped with humbuckers. This pedal is an extremely smooth OD as you can almost hear Dumble...ish type tones if you try hard enough! Well...ok, you really don't have to try hard at all!

Power Supply

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.



2.1mm x 5.5 mm tip/negative plug

Warranty

J. Rockett Audio Designs LLC will repair or replace, at its discretion, defective workmanship or materials on all new J. Rockett Audio Designs products directly or through the selling dealer or an authorized service technician for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending a product in for repair, please contact us at chris@rockettpedals.com or jay@rockettpedals.com or call us at 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration. A dated sales slip or order number (issued by a tech, dealer or J. Rockett Audio Designs) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow four (4) weeks for warranty service. For more information please contact J. Rockett Audio Designs via our website at www.rockettpedals.com or call us at 760-419-1345. No other warranty is expressed or implied.