

One Control | Mosquite Blender




Thank you for your purchase of the Mosquite Blender by One Control.

Create your own sounds limited only by your own ideas. Many months of hearing tests, component choices have gone into the development of the Mosquite Blender. All this effort was put into this small pedal.

The Mosquite Blender was designed to be used with your own pedals. Allowing you to dial in your perfect blend of wet and dry signal. Allowing you total freedom to create spacey lead tones, distorting and mixing your own original tones.

To get the full potential of the unit and to avoid misuse, please read this user guide carefully.

- 1** 9VDC INPUT: Typical 9V center negative power supplies can be used.
- 2** BLEND KNOB: By turning the Knob the right you can achieve a wet mix. Blended with the effects. With the knob turned all the way to the right, the pedals becomes a normal effects switcher.
- 3** IN FROM LOOP(RETURN): Connect this input to the output from your effects units.
- 4** OUT TO LOOP(SEND): Connect to the input of the effect.
- 5** OUTPUT JACK: This is a typical output that should be connected to your amplifier.
- 6** INPUT JACK: Plug in your instrument here using a typical instrument cable.
- 7** POLARITY REVERSE: This switch will noticeably change the nature of the sound.
- 8** FOOT SWITCH: Toggles Mosquite Blender on/off. While off the pedal has true bi-pass.
- 9** LED: Indicates when Mosquite Blender is engaged.



Specifications

INPUT: 9 Volt center negative 5mA

DIMENSIONS: 35x48x98 mm — 1.38x1.89x3.85 Inch

WEIGHT: 127g — 4.48oz.

Warranty

Repairs or exchanges under warranty are subject to these warranty guidelines:

This product is covered under our warranty for the period of 1 year from date of purchase, as filled out on the warranty card. In the case the product needs to be shipped, the cost of shipping will be paid by the buyer.

The Following are not covered by this warranty:

Fire, earthquake, natural disasters such as flooding, material breakage, or war. Warranty is void if there is any trace of repair or modification that is not performed or authorized by LEP International.

One Control by LEP International Co, LTD.

9-16 Suehiro Hanamaki

Iwate 025-0079, Japan

Phone: 0198-23-6600 Fax: 0198-29-4244

onecontrol.robert@gmail.com

www.one-control.com