



J. ROCKETT AUDIO DESIGNS



The WTF Fuzz was created in conjunction with Paul Trombetta to achieve a very musical fuzz pedal that's also really fun to play. It's the fuzz pedal for those who don't like fuzz!

Controls

- **Boost:** The boost knob is essentially an A/B volume. We did it this way so that gain structures are not affected. This allows you to achieve more volume for solo boosts and such. The WTF is very sensitive to gain structures in order to achieve sounds such as the “trombone sound”. If gain were to be added it would alter the desired sound when engaged.
- **Volume:** The volume not only affects the output but the louder it is, the thicker it gets.
- **Bypass:** The bypass switch engages the pedal.
- **Gain:** The gain knob not only affects the amount of gain but also is critical and specific for achieving the “trombone sounds”. The gain knob, in conjunction with the WTF knob, can create some pretty crazy sounds!
- **WTF:** The WTF knob is the heart of the beast! You can go from a very smooth, soulful and mild OD sound all the way up to crazy, random, low octave sounds. Dial it in just right, along with the gain knob, to achieve those awesome “trombone sounds”!
- **LED's:** The LED's indicate the bypass mode and the boost volume control.

The switch in the middle of the pedal is the EQ switch. When switched to the right the sound is the darkest and smoothest. When switched to the left the EQ setting is neutral and when switched in the middle it is the brightest. This is an extremely useful feature to pair the WTF with any given amp. The darkest setting works very well with Vox style amps. The setting to the left works very well with Fender and Marshall style amps and the setting in the middle works well with dark amps or high gain amps.

Power Supply

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.



2.1mm x 5.5 mm tip/negative

Warranty

J. Rockett Audio Designs LLC will repair or replace, at its discretion, defective workmanship or materials on all new J. Rockett Audio Designs products directly or through the selling dealer or an authorized service technician for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending a product in for repair, please contact us at chris@rockettpedals.com or jay@rockettpedals.com or call us at 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration. A dated sales slip or order number (issued by a tech, dealer or J. Rockett Audio Designs) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow four (4) weeks for warranty service. For more information please contact J. Rockett Audio Designs via our website at www.rockettpedals.com or call us at 760-419-1345. No other warranty is expressed or implied.