

electro-harmonix

22500 FOOT CONTROLLER

Remote Foot Controller for 22500 Dual Stereo Looper

Thank you for purchasing the Electro-Harmonix **22500 FOOT CONTROLLER!** The 22500 Foot Controller is a wired remote control for the 22500 Dual Stereo Looper giving your feet the ability to increment or decrement through the Loop Banks.

The 22500 Looper records and plays in up to 100 Loop Banks per SDHC card. The Foot Controller makes it easy for your feet to navigate through the 22500's 100 Loop Banks, moving up or down by either 1 or 10 banks at a time.

-CONNECTIONS -

Connect the 22500 Foot Controller (22500 FC) to your 22500 main unit using a standard 1/4" mono instrument cable. Plug one end of the cable into the jack labeled FC on the 22500 Looper. The other end of the cable should be inserted into the 22500 FC's jack at the top of the unit. The Foot Controller is now ready for use.

- FOOTSWITCHES -

LOOP UP/DOWN Footswitches – Press and release the LOOP UP footswitch to increment the Loop Bank number by 1 on the 22500 main unit. Press and release the LOOP DOWN footswitch to decrement the Loop Bank number by 1.

Press and hold either footswitch for 1 second or longer to continuously jump up or down by ten banks at a time. Release the FSW when you get to the Loop Bank decade you need. It may be helpful to have Bank displayed on the 22500 main unit while changing banks with the 22500 FC.

The Loop Bank can be changed when the 22500 is either idle (stopped) or playing back loops. If Loop A, B, or a Rhythm loop are playing at the time you change Loop Banks, all of the loops stop play upon changing banks.

The 22500 FC footswitch presses are ignored if you press either footswitch while recording or overdubbing on the 22500.

- WARRANTY INFORMATION -

Please register online at <http://www.ehx.com/product-registration> or complete and return the enclosed warranty card within 10 days of purchase. Electro-Harmonix will repair or replace, at its discretion, a product that fails to operate due to defects in materials or workmanship for a period of one year from date of purchase. This applies only to original purchasers who have bought their product from an authorized Electro-Harmonix retailer. Repaired or replaced units will then be warranted for the unexpired portion of the original warranty term. If you should need to return your unit for service within the warranty period, please contact EHX Customer Service at 718-937-8300 or info@ehx.com for a Return Authorization Number. Along with your pedal, please include a brief description of the problem as well as your name, address, telephone number, copy of your receipt, and a check or money order.

United States - \$12

Canada - \$15

Europe and other countries - \$25

Ship to:

Electro-Harmonix
C/O New Sensor Corporation
55-01 2nd Street
Long Island City, NY 11101

Attn: Service Department

Please make checks/money orders payable to New Sensor Corporation.

To hear demos on all EHX pedals visit us on the web at www.ehx.com
Email us at info@ehx.com.