

G009BE/BF



LED Open Sign

IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

BEFORE USE

You must inspect the sign including its PSU for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

PRODUCT SAFETY

- · Keep away from children.
- · Make sure the hanging chain is secure before fitting the unit
- · Switch the power supply off when not in use
- Check the unit, power supply and chain periodically for damage.

OPERATION AND FUNCTIONS

After fitting the sign in position using the chain provided, plug the power supply in to a socket and attach it to the sign via the input on the side marked 12V DC input.

The unit can be controlled by pressing the mode button on the side of the unit to select the appropriate setting.

CLEANING

Clean dust off with a paint brush or with a slightly damp cloth. Do not use strong detergents or cleaning agents as this might damage the product.

DISPOSAL AND RECYCLING

You must not dispose of this sign with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user

TECHNICAL SPECIFICATION

Code	G009BE	G009BF
Dims	510x240x50	645x330x50
Power	12V DC	12VDC
Power Supply Input	230Vac @ 50HZ	230Vac @ 50HZ
117	0.8	
0 (0)	Hanging Chain	

SERVICE WARRANTY

- Electrovision guarantees the product free from defects in materials and workmanship for a period of twelve months.
- Should this appliance be operated under conditions other than those recommended, at voltages other than the voltage indicated on the appliance, or any attempts made to service or modify the appliance, then the warranty will be rendered void.
- The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.
- · Our guarantee is administered by our retailers.
- If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Electrovision, only your retailer can arrange a replacement.
- If your product fails within the guarantee period, and needs to be repaired or replaced, you must contact the retailer from whom you bought it.
- The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order.
- If you have just received your product and require techical help in using it, please call our Help Desk on (0845) 459 4816
- If you have any other technical queires about the product, please call our Help Desk on (0845) 459 4816.

Electrovision Ltd., Lancots Lane, Sutton, St. Helens, Merseyside. WA9 3EX

website: www.electrovision.co.uk