




Please follow these steps exactly in order to enjoy a simple trouble free quick set up.




1
Unpack all contents including power supplies.




2
Insert batteries into Remote Control.




3
Select a location for the first S-Cube surround speaker, connect power cable. For left surround move switch on S-Cube to Square. For right surround select triangle.




4
Select a location for the Second S-Cube surround speaker, connect power cable and position the switch to the appropriate icon for left or right surround.




5
Position the Soundbar in front of the display (TV/Projector), connect power cable.




6
Couple the Dolby Atmos speaker onto the soundbar, it will snap into place.



7
Insert the HDMI sources into the Subwoofer.



8
Insert the HDMI output that will connect to the display.



9
Connect the power supply to the sub-woofer. The Logo will turn blue on the subwoofer.

10
The system will now power up and configure itself. The Subwoofer logo will turn blue, the Soundbar logo will light up red and the S-Cubes logo will display light blue.


Please note: On initial set up it is recommended to connect the power supply of the subwoofer last as this provides auto-power upon initial setup. If the subwoofer is powered up before the other speakers are connected you will need to power off the subwoofer either by removing the power cable or pressing the power button on the remote control until the LED turns off, then power on again by remote control.

Please note: The S-Cubes are set up to power on automatically to the surround sound system only when connected to a power supply.


Dolby, Dolby Atmos, Dolby Audio, Pro Logic, and the double-D symbol are trademarks of Dolby Laboratories

Dolby® Atmos Wireless Home Cinema System

SPEAKER GUIDE



Speaker placement



Perspektive deail

1. Seating position
2. S-cube left speaker
3. S-cube right speaker
4. S-Bar with Dolby Atmos extension
5. S-Woofer