

OWNER'S MANUAL



Soul Driver

Sample Settings



Gain



Tone



Volume



Mid Boost

Clean Buffer/Boost



Gain



Tone



Volume



Mid Boost

Full Harmonic Overdrive

Specifications

Dimensions (w/d/h): 4.39" x 2.38" x 1.98" (110mm X 60mm X 50mm)

Weight: 0.68 lbs. (309 g)

Power Consumption: 9vdc/4ma or 18v/6ma

Battery Type: 9vdc (006p) x 1

AC Adapter (optional): 9vdc, negative tips (regulated recommended) Boss PSA, Ibanez AC109, Dunlop Brick, Voodoo Labs, 1-spot etc

Input Impedance: 500k Ω (min)

Output Impedance: 10k Ω

True Bypass Switching

Internal Bass Boost Dip Switch

Notic Effects
CALIFORNIA

DC JACK

when an external power supply is used, the battery is disconnected from the circuit.

remove four screws from the bottom plate to access battery

TONE

MID BOOST

INPUT JACK

(nominal input -20dbu)
unplug when it's not in use for a longer battery life

GAIN

VOLUME

OUTPUT JACK

ON/OFF SWITCH true bypass

Internal Dipswitch Settings



	1	2
Default Settings: Boost Off (Flat)	ON	ON
Bass Boost: +2.4dB @125Hz	ON	OFF
Bass Boost: +3.6dB @125Hz	OFF	ON
Bass Boost: +6dB @125Hz	OFF	OFF