



DMX CHART – LUXIBEL B BLINDED1

1 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%

2 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%
CH2 FLASH	0-5	Open
	6-123	Flash rate, slow to fast
	124-127	Open
	128-168	LED random strobe (speed1)
	169-208	LED random strobe (speed2)
	209-249	LED random strobe (speed3)
	250-255	Open

4 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%
CH2	0-255	Dimmer Fine
CH3 FLASH	0-5	Open
	6-123	Flash rate, slow to fast
	124-127	Open
	128-168	LED random strobe (speed1)
	169-208	LED random strobe (speed2)
	209-249	LED random strobe (speed3)
	250-255	Open
CH4 DIMMER SPEED	0-063	According to the menu
	064-127	Fast
	128-191	Smooth
	192-255	Und