



TVS-1

Universal Tablet Mount by Gear4music

USER MANUAL

INTRODUCTION

Thank you for purchasing the Universal Tablet Mount by Gear4music.

To help you get the most out of your new product, please read this manual carefully.

MAIN FEATURES

Adjustable Design Fits Most Tablet Devices


Smooth and Steady Filming Using the Frame Handles

Simple to Add Additional Mics and Lights

Mount Your Tablet onto Stands and Tripods

Robust and Reliable Aluminium Construction

INSTRUCTIONS




1 - Loosen the back screw to move the adjustable section of the clamp to fit your tablet.

2 - Insert the bottom edge of your tablet into the base of the stand.

2A - Camera shoe is adjustable from 128mm - 200mm.

3 - Tighten the back screw to secure your tablet to the TVS-1.

4 - Loosen the fastening rings of the microphone or LED lighting inserts, slide the shoe into place and gently tighten the rings to keep your extra microphone or LED light in place (sold separately).



5 - Connect your microphone via your normal output or adapter.

6 - Using the base of the unit, mount onto a tripod or stand.

7 - With use of a thread adapter, you can mount onto a variety of stands, including mic stands and tripods.

Note:

- Orientate the tablet so the Home and Volume buttons are accessible when it is held by the TVS-1
- Adapters, Tripod, Microphone and Tablet available separately

SPECIFICATIONS

Net Weight: 535g

Gross Weight: 769g

Length: 348mm

Width: 248mm

Variable Distance: 128-200mm

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on +44 (0)330 365 4444 or info@gear4music.com