

Roland HPD-10 Handsonic Electronic Percussion Pad

Detailed Specifications:

Pad:	10 inches, 10 sections, Pressure-Sensitive
Instruments:	400
Percussion Kits:	64
Effect:	Ambience (5 types), Multi-Effects (20 types)
Style Guide Metronome:	70 patterns
Tempo:	40-200
Coach Mode:	QUIET COUNT, RHYTHM CHECK, TIME CHECK, PAD FOLLOW, AUTO UP/DOWN
Controls:	D Beam, Modify knob, Volume knob
Display:	Icon-driven Backlit LCD
Connectors:	Output Jacks (L/MONO, R), Phones Jack (stereo phone type), Mix In Jack (stereo phone type), Trigger Input/Foot Sw Jack (Dual), MIDI Connectors (IN, OUT)
Output Impedance:	1.0 k ohms
Power Supply:	AC Adaptor (DC 9V)
Current Draw:	1,000 mA
Accessories:	Owner's Manual, AC Adaptor (ACI/PSB-1U Series), Screw (M5 x 12) x 4 (for Mounting Plate)
Options: (Sold Separately)	Pad Stand (PDS-10), Carrying Bag (CB-HPD-10), Foot Switch (BOSS: FS-5U, FS-6), Pedal Switch (DP-2), Kick Trigger (KD-7, KD-8, etc.), Pad (PD-8, PD-85BK/WT, etc.), Cymbal (CY-8, etc.), Connection Cable (PCS-31L)
Dimensions:	
Width	323 mm - 12-3/4 inches
Depth	427 mm - 16-13/16 inches
Height	75 mm - 3 inches

For Further Enquiries on the Roland HPD-10 Handsonic Electronic Percussion Pad please call our dedicated Roland Specialist on :
0843 155 0500

