

GKBE-76 Size Chart

Alesis	VI61										
Arturia	KeyLab 88										
Casio	WK-245										
Clavia	NORD ELECTRO 2 73	NORD ELECTRO 73	NORD STAGE 73	NORD STAGE 76							
CME	UF7	UF70	VX 7								
Evolution	EKEYS 37										
Hammond	XK-1	XK-2	XK-3C								
Ketron	SD5	SD8	Solton SD-1	SX3000							
Korg	KARMA	Krome 73	M50-73	Pa3XLe	Pa4X-76	SP-500	TR76	TRITON EXTREME 61	TRITON LE 76		
Kurzweil	K2600	K2600S	PC1SE	PC3	PC3A7	PC3K7	PC3LE7	SP2	SP4-7	SP-76	
Nord	ELECTRO 2 73	ELECTRO 3 73	Electro 4 SW73	Piano 2 HA88	Piano 4	Piano 88	Stage 2 EX 88	Stage 2 EX HP76	Stage 2 HA76	Stage 2 HA88	
	Stage 2 SW73	Stage 3 88	Stage 3 HP76	STAGE 73	STAGE 76	STAGE 88					
Roland	AX-Synth	BK-9	E60	FA-07	FANTOM X7	FP-2	JUNO STAGE	Jupiter-50	RD-64	VK-7	
	VK8	VR760	XP80								
StudioLogic	Acuna88	Numa Organ	VMK-176+								
Yamaha	MOTIF XF7	MOTIF XS7	NP30	NP-31	NP-32	NP-V80	Piaggero NP-32	PSR-EW300			