

**GKB-76 SLIM Size Chart**

<b>Alesis</b>	<b>QS7.1</b>				
<b>Alesis</b>	<b>VI61</b>				
<b>Clavia</b>	<b>NORD ELECTRO 2 73</b>	<b>NORD ELECTRO 73</b>	<b>NORD STAGE 73</b>		
<b>Evolution</b>	<b>EKEYS 37</b>				
<b>Korg</b>	<b>Krome 73</b>	<b>M50-73</b>	<b>TR76</b>	<b>TRITON LE 76</b>	
<b>Kurzweil</b>	<b>SP4-7</b>				
<b>Nord</b>	<b>ELECTRO 2 73</b>	<b>ELECTRO 3 73</b>	<b>Electro 4 SW73</b>	<b>Stage 2 SW73</b>	
<b>Roland</b>	<b>AX-Synth</b>	<b>FA-07</b>	<b>FP-2</b>	<b>RD-64</b>	
<b>Yamaha</b>	<b>NP30</b>	<b>NP-31</b>	<b>NP-32</b>	<b>NP-V80</b>	<b>Piaggero NP-32</b>