

G-PG-76 Size Chart

Casio	AT5	WK-110	WK-200	WK-210	WK-225	WK-3200	WK-3300	WK-3500	WK-3700	WK-3800
	WK-500	WK-6500	WK-7500	WK-7500	YPG-225					
Hammond	XK-2	XK-3C								
Ketron	AUDYA 76	SD5	SD8	Solton SD-1	SX3000	VEGA	VEGA EX4	XD-9		
Korg	Kronos 73	Kronos X 73	M3-73	Pa2XPRO	Pa3X 76	Pa3XLe	Pa4X-76	Pa80	TRITON EXTREME 61	TRITON STUDIO 61
Kurzweil	Forte 7	Forte SE 88-key Stage Piano	K2600	K2600S	PC3LE7					
Roland	E60	G-1000	Jupiter 80	Jupiter-50	VR-700					
Yamaha	9000 Pro	DGX203	DGX230	Genos	Montage7	MOTIF XF7	MOTIF XS7	PSR-E453	PSR-EW300	PSR-EW400
	PSR-EW410	Tyros2	Tyros3	Tyros4	Tyros5-61	YPG225	YPG-235			