


HeadBones X


USER GUIDE

Settings



Charge

Charge the headphones with the included MicroUSB charging cable. The LED indicator will turn blue from red when charging is complete.



Pair


While switched off, press and hold the power button for 5 seconds to enter pairing mode, the LED indicator will flash blue and red repeatedly while in discovery.




Connect

In pairing mode, enable the Bluetooth settings in your device and select "F1", it will be connected with in seconds and there is a voice prompt by the word "connected".

Multifunction Button



	Function	Action	Prompt voice
DII	Play/pause music	Click once	None
(00)	Skip to next song	Double-click while music is playing	None
&	Answer/end call	Click once	One beep
(%)	Reject a call	Press and hold for 3 seconds	One beep
	Restore to factory settings	Press and hold both volume down button and multifunction button	Two beeps



	Function	Action	Prompt voice
(Power on/off	Press and hold power button for 3 seconds	Power on or Power off
Œ	Increase volume	Click the volume up button to adjust volume	Single beep at maximum
	Decrease volume	Click the volume down button to adjust volume	Single beep at minimum
(Enter pairing mode	With the headset switched off press and hold the volume up button until the LED flashes red and blue alternately	Pairing
	Factory Reset	Power on. Press and hold the multifunction, volume - volume + buttons simultaneously for 3 seconds	Double Beep

LED indicator

Status		LED display
Charging	*	Solid red
Charging complete	*	Solid blue
Power on	*	Flash blue once
Power off	*	Flash red once
Pairing mode	* *	Flash red and blue
Pairing complete	*	Flash blue slowly
Unpaired	*	Flash red slowly
Playing music	*	Breathing blue
Incoming call	*	Solid blue
Low battery	*	Flash red slowly

Storage and maintenance

- Always store the headset in cool and dry place. Normal working temperatures are 0-45°C (32-113°F). Working in cold/hot environment or highly humid area may reduce the life of battery.
- After long periods of no use please charge the headphones before using again.
- The headset is water resistant, but are NOT waterproof, please DO NOT submerse the headphone in water.
- Clean the headset with a soft and dry cloth.
- Ensure the charging port is dry before charging. Do not charge immediately after exercising as sweat may have entered the headset around the charging port. This could lead to damage of the headset.