

# Casio PX-735 Digital Piano, Satin Black

- **Keyboard:** 88-key piano keyboard, with Touch Response
- **Maximum Polyphony:** 128 notes
- **Tones:**
  - 18
  - Layer (excluding bass tones)
  - Split (Low-range bass tones only)
- **Effects:** Brilliance (-3 to 0 to 3), Reverb (4 types), Chorus (4 types), DSP, Acoustic Resonance
- **Metronome:**
  - **Beats:** 0, 2, 3, 4, 5, 6
  - **Tempo Range:** 20 to 255
- **Duet:** Adjustable tone range (-1 to 2 octaves)
- **Music Library:**
  - **Number of Songs:** 60, User Songs: 1 (memory capacity; up to 65KB )\*
  - **Song Volume:** Adjustable
  - **Part On/Off:** L, R
  - \*Based on 1 KB = 1024 bytes, 1 MB = 10242 bytes
- **Recorder:**
  - **Functions:** Real-time recording, playback
  - **Number of Song:** 1
  - **Number of Tracks:** 2
  - **Capacity:** Approximately 5,000 notes total
  - **Recorded Data Protection:** Built-in flash memory
- **Pedals:** Damper (with half-pedal operation), soft, sostenuto
- **Other Functions:**
  - **Touch Select:** 3 types, Off
  - **Transpose:** 2 octaves (-12 to 0 to 12)
  - **Tuning:** A4 = 440.0 Hz ±99 cents (variable)
  - **Temperament**
  - **Octave shift**
  - **Operation Lock**
- **MIDI:** 16-channel multi-timbre receive
- **Inputs/Outputs:**
  - **Phones:**
    - **Jacks:** Stereo standard jacks × 2
    - **Output impedance:** 3Ω
    - **Output Voltage:** 1.5V (RMS) MAX
  - **Power:** 12V DC
  - **USB port:** TYPE B
  - **Pedal connector**
- **Speakers:** φ 12cm × 2 (Output 8W + 8W)
- **Power Requirements:**
  - **AC Adaptor:** AD-A12150LW
- **Power Consumption:** 12V = 18W
- **Dimensions:**
  - **Digital Piano and Stand:** 137.4 (W) × 29.8 (D) × 79.2 (H) cm (54 1/8 × 11 3/4 × 31 3/16 inch)