


Yamaha DTX400K Configuration



- **Snare:** 7.5 inch pad
- **Tom:** 7.5 inch pad
- **Floor Tom:** 7.5 inch pad
- **Bass Drum:** KU100 silent kick unit
- **Hi-Hat:** 10 inch pad
- **Hi-Hat Controlling Unit:** Opened/Closed/Foot splash available (also works as second bass drum)
- **Crash Cymbal:** 10 inch pad
- **Ride Cymbal:** 10 inch pad