

PSR-SX600 SPECIFICATION CHART

PSR-SX600			
Product Name		Digital Keyboard	
Size/Weight	Dimensions (W x D x H)		1004 mm x 410 mm x 134 mm
	Weight		8.1 kg
Control Interface	Keyboard	Number of Keys	61
		Type	Organ
		Touch Response	Normal, Soft1, Soft2, Hard1, Hard2
	Other Controllers	Pitch Bend Wheel	Yes
		Modulation Wheel	Yes
		Knobs	2 (Assignable)
	Display	Type	TFT Color WQVGA LCD
		Size	480 x 272 dots (4.3 inch)
		Language	English, German, French, Spanish, Italian, Japanese
	Panel	Language	English
Voices	Tone Generation	Tone Generation Technology	AWM Stereo Sampling
	Polyphony	Number of Polyphony (Max.)	128
	Preset	Number of Voices	850 Voices + 43 Drum/SFX Kits + 480 XG Voices
		Featured Voices	73 S.Articulation!, 27 MegaVoice, 27 Sweet!, 64 Cool!, 71 Live!
	Compatibility	XG, GS (for Song Playback), GM, GM2	
Part	Right 1, Right 2, Left		
Effects	Reverb Block	52 Presets + 30 User	
	Chorus Block	106 Presets + 30 User	
	DSP Block	295 Presets + 30 User	
	Master Compressor	5 Presets + 30 User	
	Master EQ	5 Presets + 30 User	
	Part EQ	27 Parts	
	Mic Effects	Noise Gate x 1, Compressor x 1, 3-Band EQ x 1	
Style	Preset	Number of Styles	415
		Featured Styles	FreePlay:1, Pro: 372, DJ: 10, Session: 32
		Fingering	Single Finger, Fingered, Fingered On Bass, Multi Finger, AI Fingered, Full Keyboard, AI Full Keyboard, Smart Chord
		Style Control	INTRO x 3, MAIN VARIATION x 4, FILL x 4, BREAK, ENDING x 3
	Other Features	One Touch Setting (OTS)	4 for each Style
		Unison & Accent	Yes (80 Styles)
		Style Section Reset	Yes
Compatibility	Style File Format (SFF), Style File Format GE (SFF GE)		
Expandability (Expansion Packs)	Expansion Voice	Yes (approx. 100MB max.)	
	Expansion Style	Yes (Internal Memory)	
Songs (MIDI)	Preset	Number of Preset Songs	3
	Recording	Number of Tracks	16
		Data Capacity	approx. 1 MB/Song
		Recording Function	Quick Recording, Multi Track Recording
	Data Format	Playback	SMF (Format 0 & 1), XF
Recording	SMF (Format 0)		
Multi Pads	Preset	Number of Multi Pad Banks	188 Banks x 4 Pads
	Audio	Audio Link	Yes
Functions	Voices	Harmony	Yes
		Arpeggio	Yes
		Panel Sustain	Yes
		Mono/Poly	Yes
		Voice Information	Yes
	Styles	Style Creator	Yes
		OTS Information	Yes
		Song Creator	Yes
		Score Display Function	Yes
		Lyrics Display Function	Yes
		Guide	Follow Lights, Any Key, Karao-Key, Your Tempo
	Multi Pads	Multi Pad Creator	Yes
	Registration Memory	Number of Buttons	8
		Control	Registration Sequence, Freeze
	Playlist	Number of Records (max.)	500 (max.) Records per Playlist file



PSR-SX600 SPECIFICATION CHART

PSR-SX600				
Functions	USB Audio Player/Recorder	Recording Time (max.)	80 minutes/Song	
		Recording	WAV (44.1 kHz, 16-bit, stereo)	
		Playback	WAV (44.1 kHz, 16-bit, stereo)	
		Time Stretch	Yes	
		Pitch Shift	Yes	
		Vocal Cancel	Yes	
	USB audio interface		44.1 kHz, 16-bit, stereo	
	Demonstration		Yes	
	Overall Controls	Metronome	Yes	
		Tempo	5 – 500	
		Transpose	-12 – 0 – +12	
		Tuning	414.8 – 440.0 – 466.8 Hz	
		Octave Button	Yes	
	Miscellaneous	Scale Type	9 Types	
		Direct Access	Yes	
Text Display Function		Yes		
Storage and Connectivity	Storage	Internal Memory	Yes (approx. 20MB max.)	
		External Drives	USB flash drive	
	Connectivity	DC IN	16 V	
		Headphones	Standard stereo phone jack	
		Microphone	Standard mono phone jack	
		AUX IN	Stereo mini jack	
		OUTPUT	L/L+R, R	
		FOOT PEDAL	1 (Sustain), 2 (Unison), Function Assignable	
		USB TO DEVICE	Yes	
		USB TO HOST	Yes	
Amplifiers/ Speakers	Amplifiers	15 W × 2		
	Speakers	12 cm × 2		
Power Supply	Adaptor	PA-300C or an equivalent recommended by Yamaha		
	Power Consumption	17 W (When using PA-300C AC adaptor)		
	Auto Power Off	Yes		
Included Accessories		<ul style="list-style-type: none"> • Owner's Manual (this book) • Online Member Product Registration • Music Rest • AC adaptor* (PA-300C or an equivalent recommended by Yamaha) • Power cord* *May not be included depending on your area. Check with your Yamaha dealer.		
Separately Sold Accessories (May not be available depending on your locale.)		<ul style="list-style-type: none"> • AC adaptor: PA-300C or an equivalent recommended by Yamaha • Headphones: HPH-50/HPH-100/HPH-150 • Footswitches: FC4A/FC5 • Foot controller: FC7 • USB wireless LAN adaptor: UD-WL01 • Wireless MIDI adaptor: UD-BT01 • Subwoofer: KS-SW100 • Keyboard stand: L-6/L-7B (The exterior size of the PSR-SX600 is beyond the limits as described in the L-6 Assembly Instructions. However, we have determined through tests that the stand can be safely used for the instrument.)		

[DOWNLOAD MORE INFORMATION](#)