



SELMER PARIS WOODWIND MOUTHPIECES

S-80 SAXOPHONE MOUTHPIECES

ITEM #	DESCRIPTION								
E401	SOPRANO SAXOPHONE								
S401	SOPRANO SAXOPHONE								
S402	ALTO SAXOPHONE								
S404	TENOR SAXOPHONE								
S405	BARITONE SAXOPHONE								
S406	BASS SAXOPHONE								
MODEL PREFIX	INSTRUMENT TYPE		G	G*	G**	D	E	F	G
E401	SOPRANO SAXOPHONE	MODEL NUMBER		E401C1	E401C2	E401D	E401E		
		TIP OPENING		MED CLOSE 1.10	MED 1.15	MED OPEN 1.20	OPEN 1.25		
		FACING LENGTH		MED 15.00	MED 15.00	MED 15.00	MED 15.00		
S401	SOPRANO SAXOPHONE	MODEL NUMBER	S401C	S401C1	S401C2	S401D	S401E	S401F	S401G
		TIP OPENING	CLOSE 1.15	MED CLOSE 1.20	MED 1.25	MED 1.30	MED OPEN 1.35	MED OPEN 1.45	OPEN 1.55
		FACING LENGTH	MED 21.00	MED 21.00	MED 21.00	MED 21.00	MED 21.00	MED 21.00	MED 21.00
S402	ALTO SAXOPHONE	MODEL NUMBER	S402C	S402C1	S402C1	S402D	S402E	S402F	S402G
		TIP OPENING	CLOSE 1.60	MED CLOSE 1.70	MED 1.80	MED 1.90	MED OPEN 2.00	MED OPEN 2.20	OPEN 2.40
		FACING LENGTH	MED 22.00	MED 22.00	MED 22.00	MED 22.00	MED 22.00	MED 22.00	MED 22.00
S404	TENOR SAXOPHONE	MODEL NUMBER	S404C	S404C1	S404C2	S404D	S404E	S404F	S404G
		TIP OPENING	CLOSE 1.70	MED CLOSE 1.80	MED 1.90	MED 2.00	MED 2.10	MED OPEN 2.30	MED OPEN 2.50
		FACING LENGTH	MED 24.00	MED 24.00	MED 24.00	MED 24.00	MED 24.00	MED 24.00	MED 24.00
S405	BARITONE SAXOPHONE	MODEL NUMBER	S405C	S405C1	S405C2	S405D	S405E	S405F	S405G
		TIP OPENING	CLOSE 1.90	MED CLOSE 2.00	MED 2.05	MED 2.10	MED OPEN 2.20	MED OPEN 2.40	MED OPEN 2.60
		FACING LENGTH	MED 27.00	MED 27.00	MED 27.00	MED 27.00	MED 27.00	MED 27.00	MED 27.00
S406	BASS SAXOPHONE	MODEL NUMBER	S406C	S406C1	S406C2				
		TIP OPENING	CLOSE 2.00	MED CLOSE 2.10	MED 2.15				
		FACING LENGTH	MED 30.00	MED 30.00	MED 30.00				

