


















# ELECTRONIC DRUM KIT SERIES







DD500 / DD500BL / DD520





SET-UP GUIDE

# CONTENTS CHECKLIST







<p>①</p>  <p>X4</p>	<p>②</p>  <p>X2 400MM</p>	<p>③</p>  <p>X1 550MM</p>
<p>④</p>  <p>X1 350MM</p>	<p>⑤</p>  <p>X2 700MM</p>	<p>⑥</p>  <p>X2 785MM</p>
<p>Ⓐ</p>  <p>(DD520 ONLY) X1</p>	<p>Ⓑ</p>  <p>X4 for DD520 X3</p>	<p>Ⓒ</p>  <p>X1</p>
<p>Ⓓ</p>  <p>X3 for DD520 X2</p>	<p>Ⓔ</p>  <p>X2</p>	<p>Ⓕ</p>  <p>X7</p>
<p>Ⓖ</p>  <p>X2</p>	<p>Ⓖ</p>  <p>X1</p>	<p>Ⓙ</p>  <p>X4 for DD520 X3</p>



# STEP 1











## STEP 2







# STEP 3



7.







8.








## STEP 4






5.





# STEP 5










# STEP 6




# STEP 7




# STEP 8




Sound Module



Hi-Hat Pedal  
Kick



Tom1  
Tom 2  
Tom 3  
Snare



Hi-Hat  
Crash 1  
Crash 2  
Ride

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM  
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE  
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **[info@gear4music.com](mailto:info@gear4music.com)**