

Tables

To know which table is used, press the Table button. The Mode & Table LEDs indicate the selected table number by blinking. To navigate through the tables keep the Table button pressed and use the +/- Shift buttons.

01. Divider Sequences

04. Anti Euclidean

02. Classic Euclidean

05. Split Sequences

03. Revised Euclidean

Modes & Sub-modes

The Mode LEDs show the current mode. To navigate through the modes press the Mode & +/- Shift buttons. To navigate through Sub-modes, press the Mode button. The Sub-mode is shown by the Sub-modes LEDs.

MN. Main mode

RD. Random mode

01 Reset

01 No Random

02 No Shift

02 Soft Fill

03 Invert

03 Hard Fill

04 Backward

04 Full Random

CP. Compute mode

DL. Dual Mode

L = Length & P = Pulses

01 Out 2

01 L & P/2

02 Out 1

02 L/2 & P/2

RC. Rec Mode

03 2L/3 & 2P/3

01 Record

04 L-P & P/2

02 Play