


















JUNIOR DIGITAL PIANO


JDP-1-MB / JDP-1-WH

SETUP GUIDE


CONTENTS CHECKLIST

<p>A</p>  <p style="text-align: right;">X1</p>			
<p>B</p>  <p style="text-align: right;">X1</p>	<p>C</p>  <p style="text-align: right;">X1</p>	<p>D</p>  <p style="text-align: right;">X1</p>	
<p>E</p>  <p>15mm X18</p>	<p>F</p>  <p>X2</p>	<p>G</p>  <p>X4</p>	<p>H</p>  <p>27mm X4</p>
<p>I</p>  <p>X4</p>	<p>J</p>  <p>40mm X8</p>	<p>K</p>  <p>X8</p>	<p>L</p>  <p>X8</p>
<p>M</p>  <p>X2</p>	<p>N</p>  <p>X1</p>	<p>O</p>  <p>X1</p>	


TOOLS REQUIRED




1 PIANO ASSEMBLY




2



3



4 BENCH ASSEMBLY



KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**