











DIGITAL PIANO

SDP-2 / SDP-2-WH


SETUP GUIDE

CONTENTS CHECKLIST



First, check the contents of the package and make sure you have everything you need.

 1		 3	
X1		X1	
 2		 4	
X1		X1	
 A	 B	 C	 D
X4	X4	X8	X4


TOOLS REQUIRED



1



2



KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**