

About

In order to get the most out of your records, they need to be clean. Clean records sound better, have improved tracking and last longer.

Since the stylus itself cleans the contact area of the groove, only a high quality, non-abrasive and most importantly, a 'dry' record cleaning brush is required.

The **Roksan Two Stage Micro Fibre Record Cleaner** provides optimum cleaning of your record's surface and groove.

The front brush ensures general cleaning of the record surface and groove whilst the rear brush cleans the remaining dirt.

Getting started


Step One



After placing the record on the turntable, gently hold the record cleaner facing forwards on the rotating record.

Alternatively, hold the record or place on a non-abrasive surface and move the cleaner in a direction similar to a rotating record.

Step Two



After a couple of revolutions, slowly move the cleaner towards the centre.

Warning: Never use cleaning fluid or expose the fibres to liquid as this can permanently damage the record cleaner and your record or cartridge. Only use record cleaning fluids when using a dedicated record cleaning machine. Do not apply too much pressure as to stop the platter when cleaning.

Specifications

Cleaning Element
Two Stage Mirco Fibre

Replaceable Fibre Element
2mm Dense & 4.5mm Open

Contact Us

roksan.com

Roksan Audio
24 Brook Road
Rayleigh, Essex
UK, SS6 7XJ

+44 (0)1268 740580