























CHILDRENS DRUM KIT


CDK

SET-UP GUIDE

CONTENTS CHECKLIST

<p>A</p>  <p>X1</p>	<p>B</p>  <p>X2</p>	<p>C</p>  <p>X1</p>	<p>D</p>  <p>X1</p>
<p>E</p>  <p>X1</p>	<p>F</p>  <p>X1</p>	<p>G</p>  <p>X1</p>	<p>H</p>  <p>X1</p>
<p>J</p>  <p>X1</p>	<p>K</p>  <p>X1</p>	<p>L</p>  <p>X2</p>	<p>M</p>  <p>X2</p>
<p>N</p>  <p>X4</p>	<p>P</p>  <p>X1</p>	<p>Q</p>  <p>X1</p>	<p>R</p>  <p>X1</p>
<p>S</p>  <p>X4</p>	<p>T</p>  <p>X1</p>	<p>U</p>  <p>X1</p>	<p>V</p>  <p>X1</p>


KICK DRUM








(N) X4




(S) X4



KICK DRUM








5.








6.







KICK PEDAL






KICK PEDAL








RACK TOM & SNARE











CRASH CYMBAL





4.



STOOL





COMPLETED





KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**