























ELECTRONIC DRUM KIT






DD550





SET-UP GUIDE

CONTENTS CHECKLIST


<p>A</p>  <p>630mm x3</p>	<p>B</p>  <p>820mm x2</p>	<p>C</p>  <p>350mm x1</p>	<p>D</p>  <p>200mm x1</p>
<p>E</p>  <p>x3</p>	<p>F</p>  <p>700mm x2</p>	<p>G</p>  <p>785mm x5</p>	<p>H</p>  <p>x7</p>
<p>1</p>  <p>x5</p>	<p>2</p>  <p>x3</p>	<p>3</p>  <p>x1</p>	
<p>4</p>  <p>x1</p>	<p>5</p>  <p>x1</p>		
<p>6</p>  <p>x1</p>			









16.




17.






18.




19.







23.




24.




25.




26.




27.






28.




29.








33.




34.




Sound Module




Kick




Crash 1
Crash 2
Ride



Tom1
Tom 2
Tom 3
Tom 4
Snare



Hi-Hat



Hi-Hat Pedal





KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**