

Roland RP401R Specifications

Keyboard

- **Keyboard:** 88 keys (PHA-4 Standard Keyboard: with Escapement and Ivory Feel)
- **Touch Sensitivity:** Key Touch: 5 types, fixed touch
- **Keyboard Mode:**
 - Whole
 - Dual (volume balance adjustable)
 - Split (split point adjustable, volume balance adjustable)
 - Twin Piano
- **Pedals:**
 - Damper (Progressive Damper Action Pedal, capable of continuous detection)
 - Soft (capable of continuous detection)
 - Sostenuto (function assignable)

Sound Generator

- **Piano Sound:** SuperNATURAL Piano Sound
- **MIDI Format:** Conforms to GM2, GS, XGlite
- **Max. Polyphony:** 128 voices
- **Tones:** Grand Piano: 11 tones, Other: 305 tones (including 8 drum sets, 1 SFX set)
- **Stretched Tuning:** 2 types (Always On)
- **Master Tuning:** 415.3 - 466.2 Hz (adjustable in increments of 0.1 Hz)
- **Transpose:** Key Transpose: -6 - +5 (in semitones)
- **Effects:**
 - Ambience (Off, 10 levels)
 - Brilliance (21 levels)
 - **Only for Piano Tones:**
 - Damper Resonance (Always On)
 - String Resonance (Always On)
 - Key Off Resonance (Always On)

Metronome

- **Tempo:** Quarter note = 10 - 500 (When rhythm function turns on: Quarter note = 20 - 250)
- **Beat:** 2/2, 0/4, 2/4, 3/4, 4/4, 5/4, 6/4, 7/4, 3/8, 6/8, 9/8, 12/8

SMF Recorder

- **Parts:** 1 part
- **Save Song:** Standard MIDI Files (Format 0)
- **Note Storage:** Approx. 30,000 notes
- **Control:**
 - Song Select
 - Play/Stop
 - Rec
 - Rewinding
 - Fast-forwarding
 - Top of song
 - Part Mute
 - Tempo
 - All Songs Play
 - Count-in
 - Song Balance
- **Tempo:** Quarter note = 10 - 500 (When rhythm function turns on: Quarter note = 20 - 250)
- **Resolution:** 120 ticks per quarter note

Rhythm

- **Rhythms:** 72 types x 2 variations
- **Controls**
 - Rhythm Select
 - Start/Stop
 - Sync Start
 - Intro/Ending
 - Fill In
 - Variation
 - Leading Bass
 - Auto Fill
 - Rhythm Part

Audio

- **Playback:** File Format: Audio File (WAV 44.1 kHz, 16-bit linear format)
- **Control:**
 - Song Select
 - Play/Stop
 - Rewinding
 - Fast-forwarding
 - Top of song
 - All Songs Play
 - Song Balance
 - Center Cancel

Internal Memory

- **Save Song:** Standard MIDI Files (Format 0)
- **Songs:** Max. 10 songs

External Memory

- **External Storage:** USB Flash Memory
- **Playable Software:**
 - Standard MIDI Files (Format 0, 1)
 - Roland Original Format (i-Format)
 - Audio File (WAV, 44.1 kHz, 16-bit linear format)
- **Save Song:** Standard MIDI Files (Format 0)

Other

- **Internal Songs:**
 - Piano Masterpieces: 69 songs
 - Czerny: 100 songs
 - Hanon: 20 songs
- **Display:** 7 segments x 3 LED
- **Keyboard Lid:** Slide type
- **Other Functions:**
 - Wireless Connect (when using optional Wireless USB Adapter)
 - Panel Lock
 - Auto Off
- **Connectors**
 - DC In jack
 - Input jack: Stereo miniature phone type
 - Output jack: Stereo miniature phone type
 - USB COMPUTER port: USB Type B
 - USB MEMORY port: USB Type A
 - Phones jacks x 2: Stereo miniature phone type, Stereo 1/4-inch phone type
- **Rated Power Output:** 12 W x 2

- **Volume Level (SPL):** 103 dB (This value was measured according to the method that is based on Roland's technical standard.)
- **Speakers:** 8 x 12 cm (3-3/16 x 4-3/4 inches) x 2
- **Headphones:** Effects: Headphones 3D Ambience
- **Controls:** Volume (with the speaker volume and the headphones volume automatically select function, with the volume limit function)
- **Power Consumption:**
 - 9 W (3 - 22 W)
 - 9 W: Average power consumption while piano is played with volume at center position
 - 3 W: Power consumption immediately after power-up; nothing being played
 - 22 W: Rated power consumption
- **Accessories**
 - Owner's manual
 - Assembly manual
 - AC Adaptor
 - Power Cord (for AC Adaptor)
 - Headphone hook
 - Music rest
 - Screw set

Dimensions

- **Width:** 1378 mm
- **Depth:** 423 mm
- **Height:** 992 mm
- **Weight:** 40 kg