

























# VISIONDRUM+

## SET-UP GUIDE


# CONTENTS

|   |  |  |  |   |
|---|--|--|--|---|
| <p>1</p>  <p>X4</p>    | <p>2</p>  <p>X1</p>  |  |  |   |
| <p>3</p>  <p>X2</p>    |  |  |  |   |
| <p>4</p>  <p>X2</p>  | <p>5</p>  <p>X1</p> | <p>6</p>  <p>X1</p> |  |   |
| <p>7</p>  <p>X1</p>  | <p>8</p>  <p>X1</p> | <p>9</p>  <p>X3</p> |  |   |
| <p>10</p>  <p>X1</p> | <p>A</p>  <p>X1</p> | <p>B</p>  <p>X1</p>   | <p>C</p>  <p>X2</p> | <p>D</p>  <p>X2</p>  |
|   | <p>E</p>  <p>X1</p> | <p>F</p>  <p>X5</p>   | <p>G</p>  <p>X5</p> | <p>H</p>  <p>X10</p> |







7.




8.




9.




10.




11.




12.




13.








14.




15.










21.









**WWW.GEAR4MUSIC.COM**

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM  
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**