



























VISIONDRUM-PRO


SET-UP GUIDE

CONTENTS


<p>1</p>  <p>7" X3</p>	<p>2</p>  <p>X1</p>				
<p>3</p>  <p>8" X2</p>					
<p>4</p>  <p>X2</p>	<p>5</p>  <p>X2</p>	<p>6</p>  <p>X2</p>			
<p>7</p>  <p>X1</p>	<p>8</p>  <p>X1</p>	<p>9</p>  <p>X1</p>			
<p>10</p>  <p>X1</p>	<p>A</p>  <p>X1</p>	<p>B</p>  <p>10" X1</p>	<p>C</p>  <p>8" X3</p>		
	<p>D</p>  <p>X1</p>	<p>E</p>  <p>25MM X1</p>	<p>F</p>  <p>X4</p>	<p>G</p>  <p>X2</p>	
<p>H</p>  <p>30MM X1</p>	<p>J</p>  <p>X1</p>	<p>K</p>  <p>X1</p>	<p>L</p>  <p>X5</p>	<p>M</p>  <p>X3</p>	<p>N</p>  <p>X6</p>




4.




5.




6.




7.




8.




9.




10.




11.




12.




13.




14.




15.




16.









17.




18.









25.



26.







WWW.GEAR4MUSIC.COM

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**