D70X
Passive Bookshelf Speakers

User Manual

MAJORITY

HOME AUDIO • CAMBRIDGE

Contents

What's In the Box? 3
Controls & Functions 4
Product Set-up 5
Troubleshooting & Support 6
Product Specifications 6
Warranty 6
Safety Information 7

3 year Warranty

Register your product online for a FREE 3 year extended warranty at: **www.majority.co.uk**

What's in the Box?

A. Majority D70X Passive Speakers

B. Two connecting cables (2-metre crystal-clear cable, featuring a banana plug on one end and a 10mm stripped wire on the other end).

C. User Manual









Front View



1. Tweeter Speaker
2. Bass Speaker

Back View



3. "+" connects the positive end of the cable, "-" connects the negative end of the cable.
4. "+" connects the positive end of the cable, "-" connects the negative end of the cable.

Majority D70X Passive Speakers

The Majority D70X Passive Speakers cannot operate as standalone speakers. They must be connected to an electronic device with a built-in power amplifier, and the output power must not exceed 30 watts.

The D70X Passive Speakers can only be connected to the left (L) and right (R) audio channels. They cannot be connected to a subwoofer output. Whether your system is 2.0, 2.1, 5.1, or 7.1, the D70X Speakers should only be connected to the L and R channels. As long as the left and right outputs do not exceed 30 watts, the speakers are compatible.

To connect, use the speaker cables provided in the box. Each speaker comes with a 2-metre crystal-clear cable, featuring a banana plug on one end and a 10mm stripped wire on the other.

Both speakers come with their own connection cables included in the package.

Please ensure you connect the speakers correctly to the left and right channels for optimal performance.

IMPORTANT: Before connecting the Majority D70X to your amplifier or device with a built-in amplifier, please check your product user manual and ensure this can be connected to speakers like D70X.

Troubleshooting

Observation	Potential Cause/Solution
No sound	Check if all cables are correctly inserted. Check if the speakers are properly connected and the cables inserted into the correct ports. Check if your electronic device has 30 watts on the left and right ports connected to the D70X passive speakers.
Function disturbance	Disconnect from other devices. Leave the speakers off for a few minutes and then plug these back in and connect again with your device.

Product Specifications

Work power	60 Watts RMS (30 Wx2) Max
Dimensions	145 ×172×230 MM per speaker
Weight	3.6 kg

Do you still have issues? Contact Tech Support

If you require further assistance with your Majority product, please contact our team on the Majority website: **www.majority.co.uk/support** or email us @ **techsupport@majority.co.uk**

Warranty

All products come with a standard 12-month warranty. All items must be registered within 30 days of purchase via **www.majority.co.uk** for the warranty to be valid. Once on the web page, use the menu to find 'Register Your Product'. You will also be given the chance to extend your warranty for an additional 24 months, free of charge.