MOGER

MOD FACTORY

Modulation effect Pedal

Owner's Manual

Precautions

PLEASE READ CAREFULLY REFORE PROCEEDING

Power Supply

Please connect the designated AC adapter to an AC outlet of the correct voltage. Please be sure to use only an AC adapter which supplies 9V (±10%) DC, center minus. The maximum working voltage shall not exceed 12V, otherwise may be dangerous equipment damage, fire or other problems.

Unplug the AC power adapter when not using or during electrical storms.

Connections

Always turn off the power of this and all other equipment before connecting or disconnecting, this will help prevent malfunction and / or damage to other devices. Also make sure to disconnect all connection cables and the power cord before moving this unit.

Cleaning

Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

· Heat sources

- · Direct sunlight
- Magnetic fields
- · Excessive dusty or dirty location
- · Strong vibrations or shocks

FCC certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

- Collected 11 kinds of classic modulation effect
- Using 32bit high performance DSP chip, each tone is comparable with other pedals' tone
- Full metal shell
- Very small and compact design
- True bypass switch


· Extreme temperature or humidity

· High humidity or moisture

DC 9V adapter power supply

Panel Instruction

2. ON/OFF LED:



AS SHOWN IN FIGURE

parameter table

CTRL1

rate

rate

rate

rate

rate

rate

rate

rate

sens

sens

Effects

Chorus

Flanger

Phaser

Env phser

Tremolo

Sttuter

Vibrato

Univibe

Auto wah

Env Ring

Touch wah

Name

СН

PH

TR

ST

VB

UV

AW

effect is engaged. 3. DC IN Power Jack: For power supply, use a 9-volt DC regulated AC adapter (plug polarity is positive on the barrel and negative in the center). 4. INPUT Jack: 1/4" mono audio jack, for connecting quitar. 5. OUTPUT Jack:

1/4" mono audio jack, outputs the signal. 6. Control 1 Knob:

1. TRUE BYPASS Footswitch: Push down the footswitch to togale

between on and bypass status.

Shows the on/off status of Mod Factory, when the LED is lit the

Adjusts the speed or the sensitivity of effect

7. Control 2 Knob:

Adjusts the level or the tone of sound.

8. DEPTH Knob:

Adjusts the depth of modulation effects.

9. MOD Knob:

Adjusts the modulation effects.

NOTE: Due to different modulation effects, there exsit differences on the parameter names, thus one knob has are two kinds of identification.

Specification

Input: 1/4" monaural jack (impedance: 470k Ohms) Output: 1/4" monaural jack (impedance: 100 Ohms)

CTRL2

level

tone

level

tone

tone

tone

level

level

level

tone

Power Requirements: AC adapter 9V DC (center minus plug).

recommended to use Mooer Micro Power

Current Draw: 128 mA

Dimensions: 93.5mm (D) × 42mm (W) × 52mm (H)

Weight: 170a

Accessories: Owner's Manual

Disclaimer: Any specification's update won't be amended in this manual.